


Bluetooth IntaRide Radio Dongle - 1



Instructions

Pairing:

- 1) Make sure BOTH devices are fully charged and within 1 metre of each other. Turn off ALL Bluetooth devices - phones, music players etc that are within 10 metres.
- 1) Power OFF the BIRD-1 and the Bluetooth headset.
- 2) Press and hold the Pairing Button on the BIRD-1 for approximately 8 seconds until the light quickly flashes Red/Blue continuously.
- 3) Using your Bluetooth headset's instructions, put it into "Pairing Mode" until the BIRD-1 flashes change to blue slowly to indicate pairing has been established. This may take a few minutes.
- 4) Plug the radio connector lead into your radio and the PTT button and lead into the Radio dongle. Press the PTT to confirm that the radio goes into transmit correctly.
- 5) If using a Bluetooth PTT button. Turn OFF your paired headset and the BIRD-1. Press and hold the Bluetooth PTT button until the light flashes Red / Blue rapidly. Press and hold the BIRD-1 power button until the light flashes Red / Blue rapidly, wait 5 seconds and press the BIRD-1 power button ONCE, the flashing lights will slow down and in a few seconds the two devices will cease flashing and go to a slow blue light flash to indicate successful pairing.

Instructions

- 6) You should be able to hear received transmissions from other radios through your Bluetooth headset and also be heard when transmitting. Use the volume adjustment on the radio to set the incoming sound as loud as comfortable without distortion in your headset, then adjust the volume with your Bluetooth headset thereafter. Be aware that some Bluetooth headsets take several seconds to “wake-up” from sleep mode after a period of non-use. This cannot be affected by the BIRD-1.
- 7) When you have finished use of the Radio dongle, a long (10 second) press of the “Pairing Button” will shut the unit OFF. The Bluetooth PTT will receive a signal to shut down.

Power:

- 1) Charge your BIRD-1 using the mains 240v to 5v USB adapter provided, using the USB lead provided. Red flashing light indicates charging which changes to solid red when charging is complete
- 2) You can power the Radio dongle from your vehicle using a suitable USB adapter that has a 5v output.

Lights:

OFF:	Power off
Red/blue quick flash:	Preparing for Pairing mode
Red/blue slow flash:	Pairing mode
Red flash 2x per 10 seconds:	Battery Low
Red flash 1x per second:	Charging
Red solid:	Fully charged
Blue flash 1x per 3 seconds:	Standby mode
Blue solid:	Working mode

If you encounter any problems please call IntaRide on 01527 908044 or check the website www.intaride.com.

Engineering services can be contacted on support@intaride.com