

Kenwood 15 channel Radios to IntaRide PMR446 Radio Frequency Guide

The Kenwood channels also contain CTCSS (Sub channels) so, in order to have proper 2-way communications, you must set the PMR446 radio to both the main channel AND the CTCSS channel as indicated

Kenwood Channel No	PMR446 Channel No.	CTCSS
1	1 :	10
2	8 :	08
3	3 :	13
4	6 :	05
5	4 :	17
6	2 :	18
7	7 :	19
8	5 :	07
9	1 :	14
10	8 :	15
11	3 :	16
12	6 :	06
13	-----	
14	-----	
15	-----	