

BASIC FUNCTIONS:

Power-ON:

Press and hold 'Function' wheel AND the 'Intercom' button until the (Main) LED indicator flashes blue.

Power-OFF:

Press and hold 'Function' wheel AND the 'Intercom' button until the (Main) LED indicator flashes red.

Function Channel Pairing:

(these are not technical terms, just terms we use to identify each connection)

Press and hold the 'Function' wheel to start searching sequence (fast Red/Blue flash).

Intercom Channel Pairing:

(these are not technical terms, just terms we use to identify each connection)

Press and hold the 'Intercom' button to start searching sequence (slow Red/Blue flash).

Volume Up:

Rotate 'Function' wheel anti-clockwise to raise the volume.

Volume Down:

Rotate 'Function' wheel clockwise to lower the volume.


Reset Pairings:

Press and hold the 'Previous' button and the 'Function' wheel at the same time, the LED indicator will flash purple (red & blue).

CONNECTION INDICATION:

When there is a blue light in the connection indication crescent, this means the units are paired and connected.

MODULAR PAIRING SEQUENCE



THE 'M' (MASTER) UNIT SHOULD ALWAYS BE IN THE CENTER OF THE 'CHAIN'

(As displayed above, the A unit is connected to the M unit, which is then connected to the B unit this ensures that there is equal distance between the first unit, Master unit and last unit).

CONNECTING TWO UNITS:

A Unit - Press and hold the 'Function' wheel (fast Red/Blue flash).

M Unit - Press and hold the 'Intercom' button (slow Red/Blue flash).

'A Unit' and 'M Unit' are now paired and connected.

CONNECTING THREE UNITS:

M Unit - Press and hold the 'Function' wheel (fast Red/Blue flash).

B Unit - Press and hold the 'Intercom' button (slow Red/Blue flash).

'M Unit' and 'B Unit' are now paired and connected.

To connect more units (up to eight units manufacturer rated, we recommend six) on the last unit paired press and hold the 'Function' wheel (fast Red/Blue flash), while on the new unit you want to add to the 'chain', Press and hold the 'Intercom' button (slow Red/Blue flash).

When you turn off your units, when you turn them back on, press and release the 'Intercom' button on the 'M unit' to reconnect them all.

PAIRING TO GPS/PHONE

1. Turn your S-3 units on.
2. Press and hold the function button/wheel until the LED indicator is flashing red/blue alternately.
3. Go to your phone/GPS Bluetooth settings and search/scan for SCS S-3.
4. Select and pair to the S-3.

To switch between intercom (talking to rider/pillion via S-3) and your phone/GPS (music etc) press and release the intercom button.

Switching between songs:

Previous button:

Previous Song.

Next button:

Next Song.

Note: Give the unit some time to send and receive AVRCP, if the song doesn't change instantly.

PAIRING TO BIRD-1

1. Turn your S-3 unit on.
2. Make sure the S-3 IS NOT connected (It can be paired but there should be no audio between any other unit AND no connection indication light).
3. Press and hold the intercom button until the LED indicator is flashing red/blue alternately.
4. While the BIRD-1 is powered OFF, press and hold the on button until the BIRD-1's LED indicator is flashing red/blue alternately.
5. The BIRD-1 and S-3 will automatically pair to each other.

To switch between intercom (talking to rider/pillion via S-3) and your BIRD-1 (radio channel communication) press and release the intercom button.

SPRING CLIP INSTALLATION

1. Retrieve your S-3 dock and spring clip.
2. Look at the bottom of the S-3 dock and notice 2 rectangular slots.
3. Squeeze the spring clip and push into place.

